

Starting the Engine	26
Steering Lock	25
Stopping Engine	100
Storage	
Equipment	29
Owner's Manual	29, 100
Storing Your Motorcycle	104
Switches	24
T	
Tachometer	18
Throttle	75
Tires	
Air Pressure	45
Puncture	84
Replacing	45, 84
Transporting Your Motorcycle	104
Tripmeter	19, 100
Troubleshooting	79
Turn Signal Indicator	22
Turn Signal Switch	24
V	
Vehicle Identification Number	106
W	
Warning Indicators On	82
Warranty Coverage and Service	115
Washing Your Motorcycle	101
Weight Limit	15, 119
Wheels	
Front Removal	85
Rear Removal	88