


N Neutral indicator

Comes on when the transmission is in Neutral.

High beam indicator**High coolant temperature indicator**

Comes on briefly when the ignition switch is turned to the ON position.

If it comes on while riding: ➔ P.87

ABS (Anti-lock Brake System) indicator CB300FA

Comes on when the ignition switch is turned to the ON position. Goes off when your speed reaches approximately 6 mph (10 km/h).

If it comes on while riding: ➔ P.88