

Engine

Number	114
Oil	43, 62
Oil Filter	64
Overheats	87
Starting	27
Stop Switch	106
Stopping	106
Will Not Start	86

Environment	113
--------------------------	-----

Equipment

Owner's Manual	30, 106
Tool Kit	30

F

Flooded Engine	27
-----------------------------	----

Front Seat	55
-------------------------	----

Front/Rear Turn Signal Light	99
---	----

Fuel

Gauge	19
Recommended	29
Remaining	19
Tank Capacity	29

Fuses	42, 101
--------------------	---------

G

Gasohol	121
----------------------	-----

Gasoline	29
-----------------------	----

H

Headlight	98
------------------------	----

Headlight Aim	83
----------------------------	----

Headlight Dimmer Switch	24
--------------------------------------	----

Helmet Holder	30
----------------------------	----

High Beam Indicator	23
----------------------------------	----

High coolant temperature indicator	23
---	----

Honda Contacts	124
-----------------------------	-----

Horn Button	24
--------------------------	----

I**Ignition Cut-off System**

Banking Sensor	106
----------------------	-----

Side Stand	73
------------------	----

Ignition Key	105
---------------------------	-----

Ignition Switch	25, 27, 106
------------------------------	-------------

Indicators	22
-------------------------	----

Information Record	130
---------------------------------	-----

Instruments	18
--------------------------	----