

Speedometer

Tachometer


NOTICE

Do not operate the engine in the tachometer red zone. Excessive engine speed can adversely affect engine life.

Tachometer red zone
 (excessive engine rpm range)

Clock (12-hour display)
 To set the clock: P. 24
Fuel gauge

Remaining fuel when only 1st (E) segment starts flashing:
 approximately 0.85 US gal (3.2 liters)



If the fuel gauge indicator flash sequentially or turned off: P. 93