

Speedometer

Tachometer

NOTICE

Do not operate the engine in the tachometer red zone. Excessive engine speed can adversely affect engine life.

Tachometer red zone


(excessive engine rpm range)

Clock (12-hour display)

To set the clock: P.25

Fuel gauge

Remaining fuel when only 1st (E) segment starts flashing:
approximately 0.85 US gal (3.2 L)



If the fuel gauge indicator flashes in a repeat pattern or turns off: P.94