

Engine

Number	115
Oil	52, 65
Oil Filter	67
Overheats	91
Starting	35
Stop Switch	32, 35, 109
Stopping	109
Will Not Start	90

Environment	114
--------------------------	-----

Equipment

Owner's Manual	39, 109
Tool Kit	39

F

Flooded Engine	35
-----------------------------	----

Front Seat	62
-------------------------	----

Front Suspension	87
-------------------------------	----

Fuel

Consumption Meter	20
Gauge	19
Mileage Meter	20
Oxygenated	122
Recommended	37

Remaining	19
Tank Capacity	37

Fuses	51, 105
--------------------	---------

G

Gasohol	122
----------------------	-----

Gasoline	37
-----------------------	----

H

Hazard Switch	32
----------------------------	----

Headlight Aim	85
----------------------------	----

Headlight Dimmer Switch	32
--------------------------------------	----

Helmet Holder	38
----------------------------	----

High Beam Indicator	31
----------------------------------	----

High Coolant Temperature Indicator ..	30, 91
--	--------

Honda Contacts	126
-----------------------------	-----

Horn Button	32
--------------------------	----

I**Ignition Cut-off System**

Banking Sensor	109
Side Stand	75

Ignition Key	108
---------------------------	-----

Ignition Switch	33, 35, 109
------------------------------	-------------