


The average fuel mileage and fuel consumption will be based on tripmeter A.

- Current fuel mileage:  
Current instant fuel mileage. If your speed is less than 5 mph (7 km/h), "--.-" is displayed. When "--.-" is displayed at speeds above 5 mph (7 km/h), go to your dealer for service.
- Average fuel mileage:  
Average fuel mileage since tripmeter A was reset. When "--.-" is displayed, go to your dealer for service.
- Fuel consumption:  
Total fuel consumption since tripmeter A was reset. When "---.-" is displayed, go to your dealer for service.

► **To reset the average fuel mileage and fuel consumption:**  **P.22**