


Adjusting the Windscreen Height

You can adjust the windscreen height 1 of 2 positions.

1. Remove the windscreen by removing the bolts.



2. Install the right and left bolts to the low position holes or high position holes.

