

## Gauges, Indicators & Displays

3	low fuel indicator (amber)	<p>When this indicator comes on while riding, fuel reserved in the tank is about: <b>0.92 US gal (3.5 l)</b> <i>Lamp Check.</i></p> <p>When this indicator comes on, the lower segment of the multi-function display switches to the reserve fuel consumption (page 28 ).</p>
4	neutral indicator (green)	Lights when the transmission is in neutral.
5	tachometer	Shows engine speed in revolutions per minute (rpm). <i>Meter Check.</i>
6	high beam indicator (blue)	Lights when the headlight is on high beam. <i>Lamp Check.</i>