

## Odometer [TOTAL] & Tripmeter [A/B]

**A** button switches between odometer and tripmeters.

When the fuel mileage meter is displayed, press **A** button to select the odometer or tripmeter A.

- Odometer: Total distance ridden.
- Tripmeter: Distance ridden since tripmeter was reset.

► **To reset the tripmeter:** **P.23**

