

Stopping	128
Environment.....	136

F

Flooded Engine	46
Front Brake Lever Adjustment	94
Front Seat	72
Front Suspension.....	95

Fuel

Consumption Meter.....	24
Low Fuel Indicator.....	41, 43
Mileage Meter	24
Oxygenated	144
Recommended.....	48
Remaining.....	41, 43
Tank Capacity	48

Fuses	62, 123
-------------	---------

G

Gasohol.....	144
Gasoline.....	48

H

Headlight Aim	104
Headlight Dimmer Switch.....	44
Helmet Holder	50
HESD (Honda Electronic Steering Damper)	129
HESD (Honda Electronic Steering Damper) Indicator	41
High Beam Indicator	40
High Coolant Temperature Indicator	40, 107
Honda Contacts.....	148
Horn Button.....	44

I

Ignition Cut-off System

Banking Sensor.....	129
Side Stand	85
Ignition Key	127
Ignition Switch	44, 45, 128
Indicators	40
Information Record.....	155
Instruments.....	22