

## INFO 3 display

You can select the following:

- CBR Logo
- Shift indicator set value [REV IND NE]
- Throttle grip angle [GRIP ANGLE]
- Battery voltage [VOLTAGE]
- Date [DATE]
- User letter
- Blank display

## Changing the INFO 3 display

- 1 Select the INFO 3 display. P.27
- 2 Press the (up) or (down) button until the desired display is displayed.
- 3 Press the button. The INFO 3 display is set, and then the display moves to the riding mode display.

