

Instruments (Continued)





To End the Setting

Select the "EXIT" menu on the main menu screen, or press and hold the MODE button and SEL (up) or SEL (down) button. Also, the setting mode is ended when your motorcycle speed reaches approximately 1 km/h (1 mph).

Note that doing so cancels the settings left incomplete.