## **Instruments** (Continued)

When selecting the "L/100 km"

- Units of the current fuel mileage and average fuel mileage show "L/100 km".
- Units of the tripmeter A fuel consumption and amount of remaining fuel show "L".

When selecting the "km/L"

- Units of the current fuel mileage and average fuel mileage show "km/L".
- Units of the tripmeter A fuel consumption and amount of remaining fuel show "L".

## RESTORE DEFAULT

The set value can be returned to default setting.

- 1 Select the "NO" (not restore) or "YES" (restore) using the SEL ▲ (up) or SEL ▼ (down) button.
- 2) When the "NO" is selected

Press the MODE button. The set value is maintained, and then the display returns to the upper level hierarchy.

## When the "YES" is selected

Press the MODE button. The display changes to the confirmation screen.

