



## Riding mode *(Continued)*

### 10 CBR1000S1

Press the **SEL**  (up) or  (down) button until the desired mode is displayed.

11 Press and hold the **MODE** button until ordinary display is displayed.

You can stop setting the riding modes at any time by pressing and holding the **MODE** button.