Numerical tachometer Display [REV]

Displays engine revolutions per minutes. Display range: 0 to 15,400 r/min (rpm)

• Above 15,400 r/min (rpm): "15400" is displayed.

> RFV 7000 r/min

Current fuel mileage [INST. CONS.]

Displays the current instant fuel mileage. Display range: 0.0 to 99.9 MPG (mile/L, L/ 100km or km/L)

- When your speed is less than 4 mph (7 km/h): "--.-" is displayed.
- Above 99.9 MPG (mile/L or km/L):"99.9" is displayed.
- Above 99.9 L/100km: "--.-" is displayed.

INST. CONS. 2.0 MPG

When "--.-" is displayed except for the above-mentioned cases, go to your dealer for service.