## **Instruments** (Continued)

## **Reserve Fuel Mode**

When the low fuel indicator lights and the low fuel pop-up information appears, the available riding distance is indicated, and the amount of remaining fuel display can be selected.

You should refill the tank as soon as possible.

Remaining fuel amount turned to the reserve fuel mode:

1.1 US gal (4.0 L)



After refueling more than the reserve amount, the display returns to normal when the ignition switch has been ON position for about a minute.