Instruments (Continued)

When selecting the "L/100 km"

- Units of the current fuel mileage and average fuel mileage show "L/100 km".
- Units of the tripmeter A fuel consumption and amount of remaining fuel show "L".

When selecting the "km/L"

- Units of the current fuel mileage and average fuel mileage show "km/L".
- Units of the tripmeter A fuel consumption and amount of remaining fuel show "L".

RESTORE DEFAULT

The set value can be returned to default setting.

- 1 Select the "NO" (not restore) or "YES" (restore) using the SEL ▲ (up) or SEL ▼ (down) button.
- When the "NO" is selected

Press the MODE button. The set value is maintained, and then the display returns to the upper level hierarchy.

When the "YES" is selected

Press the MODE button. The display changes to the confirmation screen.

