


Instruments (Continued)

To Measure the Lap Time

- 1 Press and hold the **LAP** button or select the "CIRCUIT" menu on the "DISPLAY MODE" menu screen. **➡ P.24** **➡ P.58** **➡ P.59**
- 2 To start measuring, press the **LAP** button.
 - ▶ The stopwatch starts measuring.



- 3 To record lap time, press the **LAP** button at each lap.
 - ▶ The stopwatch changes to display the difference with the best lap. After 10 seconds, the display will return to the stopwatch.
 - ▶ The previous lap time and previous lap number change to the information of the previous lap.
 - ▶ If you press the **LAP** button again within two seconds, lap time is not recorded.
 - ▶ When exceeds 50 lap, the previous lap number repeats the "LAP 50".