## Riding mode (Continued)

10 CBR1000S1/S2

Press the SEL (up) or SEL (down) button until the desired mode is displayed.

1) Press and hold the MODE button until ordinary display is displayed.

You can stop setting the riding modes at any time by pressing and holding the MODE button.