

Instruments *(Continued)*

The established setting can also be set by turning the ignition switch to the OFF position.

The control is automatically switched from the setting mode A to the ordinary display if the button is not pressed for about 30 seconds. Even in this case, established setting is maintained.