
## Refueling



Do not fill with fuel above the level plate. Fuel type: Unleaded gasoline only Recommended fuel octane number: Pump Octane Number (PON) 86 or higher. **Tank capacity:** 4.41 US gal (16.7 liters)

Refueling and Fuel Guidelines P. 13



## Opening the Fuel Fill Cap

Open the lock cover, insert the ignition key, and turn it clockwise to open the cap.

## Closing the Fuel Fill Cap

- 1 After refueling, push the fuel fill cap closed until it locks
- 2 Remove the key and close the lock cover.
  - The key cannot be removed if the cap is not locked

## AWARNING

Gasoline is highly flammable and explosive. You can be burned or seriously injured when handling fuel.

- Stop the engine, and keep heat, sparks, and flame away.
- Handle fuel only outdoors.
- Wipe up spills immediately.