

Equipment

Owner's Manual	30, 103
Tool Kit.....	30

F

Flooded Engine	27
Front Brake Lever Adjustment.....	74
Front Seat	52
Front Suspension	75

Fuel

Gauge	19
Recommended	29
Remaining.....	19
Tank Capacity	29

Fuses.....	42, 98
------------	--------

G

Gasohol	117
Gasoline	29

H

Headlight Aim	74
Headlight Dimmer Switch	24
Helmet Holder	30

HESD (Honda Electronic Steering

Damper).....	103
HESD (Honda Electronic Steering Damper)	
Indicator.....	23
High Beam Indicator.....	23
High Coolant Temperature Indicator ...	22, 82
Honda Contacts	120
Horn Button	24

I**Ignition Cut-off System**

Banking Sensor.....	103
Side Stand.....	65

Ignition Key	102
---------------------------	-----

Ignition Switch	25, 27, 102
------------------------------	-------------

Indicators	22
-------------------------	----

Information Record	126
---------------------------------	-----

Instruments	18
--------------------------	----

L

Labels	7
---------------------	---

Load Limits	15
--------------------------	----

Loading Guidelines	15
---------------------------------	----

Low Oil Pressure Indicator	22, 83
---	--------