


## Clip

### Removal

1. Remove the pin by a Phillips screwdriver.
2. Pull the clip out of the hole.



### Installation

1. Insert the clip into the hole.
2. Push the pin in.

