

Maintenance

Please read “Importance of Maintenance” and “Maintenance Fundamentals” carefully before attempting any maintenance. Refer to “Specifications” for service data.

Importance of Maintenance	P. 33	Other Adjustments	P. 70
Maintenance Schedule	P. 34	Adjusting the Headlight Aim	P. 70
Maintenance Fundamentals	P. 37		
Tool	P. 48		
Removing & Installing Body Components ..	P. 49		
Battery	P. 49		
Battery Cover.....	P. 50		
Spark Plug	P. 51		
Engine Oil	P. 53		
Brakes	P. 56		
Side Stand	P. 63		
Drive Chain	P. 64		
Throttle	P. 68		
Crankcase Breather	P. 69		