

## Changing Air Cleaner Element

Use a new Honda Genuine air cleaner element or an equivalent specified for your motorcycle.

### NOTICE

Using the wrong air cleaner element may cause premature engine wear or performance problems.

1. Remove the left side cover. 2 P. 66
2. Disconnect the wire connector of the starter magnetic switch. 2 P. 110
3. Remove the harness band clip from the air cleaner housing cover. 2 P. 64
4. Remove the air cleaner housing cover by removing the screws.

