


Riding mode display ➔ P.64

Odometer [TOTAL]/Tripmeter  
[TRIP A/B]/Riding mode display

➔ P.28 ➔ P.64

Current fuel mileage [CONS.]/Average  
fuel mileage [AVG. CONS.]/Average  
speed [AVG. SPD.]/Subtraction trip  
[-TRIP]/Available driving distance  
[RANGE] display ➔ P.31

Air temperature gauge [AIR] display/  
Elapsed time [ELAPSED] ➔ P.37



→ Press the **MODE** button