




## Instruments *(Continued)*

### Odometer [TOTAL] & Tripmeter [TRIP A/B] & Riding mode display

The **SEL**  (up) or the **SEL**  (down) button selects the odometer, the tripmeter A, tripmeter B and riding mode when this display is selected.



### Odometer

Total distance ridden. When "-----" is displayed, go to your dealer for service.

### Tripmeter A/B

Distance ridden since tripmeter was reset.

When "-----." is displayed, go to your dealer for service.

**To reset the tripmeter:**  **P.29**

**Riding mode**  **P.64**