

Instruments *(Continued)*

Press the **MODE** button to move the cursor to a desired display.

Handle grip heater status icon

CRF1000A II/D II

The handle grip heater status icon will appear while the handle grip heater is on. ➔P.58

EB level ➔P.64

P level ➔P.64

Torque Control level ➔P.61 ➔P.64

