


Storage Equipment

Helmet holder

A helmet holder is located under the front seat.

The helmet set wire is secured with the rear fender under the front seat. ➔P.83



► Use the helmet holder only when parked.

Removing the front seat ➔P.110

⚠WARNING

Riding with a helmet attached to the holder can interfere with the rear wheel or suspension and could cause a crash in which you can be seriously hurt or killed.

Use the helmet holder only while parked. Do not ride with a helmet secured by the holder.