

## Audio System *(Continued)*

- 7 The device name and Passkey appear on the screen. Select [Yes], and then press the **ENT** switch.



- 8 When the pairing is complete, the name of the paired device are displayed.  
Icon status:

 : Phone function connected

 : Music function connected



- 9 Return to the riding information, previous screen or Home screen. **P.38**  
You can also perform the above settings by using the touch screen.