

13. Raise the front wheel off the ground again, and check that the wheel rotates freely after you release the brake.
14. Remove the protective tape or cloth.

If a torque wrench was not used for installation, see your dealer as soon as possible to verify proper assembly. Improper assembly may lead to loss of braking capacity.

Rear Wheel

Removal

1. Support your vehicle securely and raise the rear wheel off the ground using a maintenance stand or a hoist.
2. **CRF1100D/D4**
Release the parking brake. 2 P. 125

3. **CRF1100A/A4**

Cover both sides of the rear wheel, spoke and brake caliper with protective tape or cloth.

CRF1100D/D4

Cover both sides of the rear wheel, spoke and rear brake and parking brake calipers with protective tape or cloth.

