

# Maintenance Schedule

Items		Frequency	Whichever Comes First	Regular Maint. Interval					Refer to page:	
			⇔	mi	100	600	1,200	1,800		2,400
				km	150	1,000	2,000	3,000		4,000
		Note	Month	1	6	12	18	24		
*	Fuel Line					I		I	–	
*	Throttle Operation					I		I	73	
	Air Cleaner	Note 1			C	C	C	C	68	
	Crankcase Breather				I	I	I	I	72	
	Spark Plug				I	I	I	I	79	
*	Valve Clearance			I	I	I	I	I	–	
	Engine Oil			R	R	R	R	R	62	
**	Engine Oil Strainer Screen					C		C	–	
**	Engine Oil Centrifugal Filter					C		C	–	
**	Engine Idle Speed			I	I	I	I	I	78	

\* Should be serviced by your dealer, unless the owner has the proper tools and service data and is mechanically qualified. Refer to the official Honda Service Manual ([page 162](#)).

\*\* In the interest of safety, we recommend these items be serviced only by your dealer.