

## Storing Your Honda

---

5. Remove the battery and charge it fully. Store it in an area protected from freezing temperatures and direct sunlight. Slow charge the battery ([page 116](#)) once a month.
6. Wash and dry your motorcycle.
7. Lubricate the drive chain ([page 110](#)).
8. Inflate the tires to their recommended pressures ([page 101](#)).
9. Store your motorcycle in an unheated area, free of dampness, away from sunlight, with a minimum of daily temperature variation.
10. Cover your motorcycle with a porous material. Avoid using plastic or similar non-breathing, coated materials that restrict air flow and allow heat and moisture to accumulate.

### Removal from Storage

1. Uncover and clean your motorcycle.
2. If your motorcycle has been stored for more than four months – change the engine oil ([page 66](#)).
3. If your motorcycle has been stored for more than two months – drain and replace the fuel.
4. Charge the battery ([page 116](#)) as required. Install the battery.
5. Lubricate the drive chain ([page 110](#)).
6. Perform a pre-ride inspection ([page 24](#)), then test-ride your motorcycle at low speeds.