## **Quick Reference**

These symbols are used in Operating Controls section:

SYMBOL	COMPONENT	SEE PAGE
N	choke lever	16
0	ON – ignition switch	17
OFF	OFF – ignition switch	17
(3)	START button	18
$\boxtimes$	engine stop button	18