

Drive Chain ► Adjusting the Drive Chain Slack

5. Inspect the sprockets. P. 46
6. Clean and lubricate the drive chain.
 P. 47

Adjusting the Drive Chain Slack

Adjusting the chain requires special tools. Have the drive chain slack adjusted by your dealer.

1. Place your motorcycle on the side stand on a level surface.
2. Stop the engine. Place the transmission in Neutral.
3. Loosen the rear axle nut.
4. Loosen the lock nuts on both adjusting bolts.

