Drive Chain ► Adjusting the Drive Chain Slack

I Checking the Drive Chain Wear

Check the chain wear label when adjusting the drive chain. If the indicator groove on the chain adjuster plate enters the red zone on the label after the chain has been adjusted to the proper slack, the chain is excessively worn and must be replaced.

Chain: DID 520VF

If necessary have the drive chain replaced by your dealer.

