

G

gap, spark plug67
gasohol153
gasoline.....40
gearing137
guidelines,
 steering damper135
 suspension adjustment130

H

handlebar inspection.....105
Honda,
 contacting161
 Rider's Club163
 service manual.....160

I

identification, vehicle148
idle speed, engine61
indicator,
 MIL blink7
 circuit inspection8
 DTC index9
inspection, pre-ride13
instruments5

L

labels, safety4
logbook, competition.....154

M

maintenance,
 after competition30
 before & after competition30
 between motos & practice30
 component locations32
 general competition.....26
 importance.....22
 safety23
 schedule.....24
manual, service.....160
modifications3

O

oil,
 engine49
 fork87
 transmission52
operating instructions15
operation component locations6
optional,
 parts list156
 sprockets.....137
oxygenated fuels.....153

P

pads, brake.....93
parts, optional156
personal fit adjustments139
pinging, engine40
plug, spark67
pre-load, rear suspension.....125
pre-ride inspection.....13
protective apparel2

R

rear suspension maintenance125
Rider's Club Honda (USA only).....163
riding,
 apparel2
 basic operation15
 before.....11
 important safety information.....2
 safety precautions.....2

S

safety,
 a few words aboutSafety Messages
 important information2
 important precautions.....2
 labels4
 maintenance.....23
 riding precautions.....16
 schedule, maintenance.....24
seat33
serial numbers148
service,
 customer162
 manuals160
spare parts.....157
spark knock40
spark plug,
 maintenance.....67
 reading.....133
specifications149
spring pre-load, rear suspension125
starting,
 engine17
 troubleshooting.....145
steering damper,
 adjustment.....134
 guidelines135
 operation inspection.....104
steering stem inspection105

(cont'd)