

ADJUSTMENTS FOR COMPETITION... 111	TIPS.....143	INDEX166
Front Suspension Adjustments 112	Transporting Your Motorcycle144	
Front Suspension Air Pressure 112	Storing Your Honda145	QUICK REFERENCE
Front Suspension Damping 112	Preparation for Storage145	
Fork Springs 113	Removal from Storage145	
Front Suspension Disassembly..... 114	You & the Environment146	
Damper Oil Change..... 117	Troubleshooting147	
Fork Assembly 120		
Rear Suspension Adjustments 127	TECHNICAL INFORMATION.....149	
Rear Suspension Spring Pre-Load..... 127	Vehicle Identification150	
Rear Suspension Damping 128	Serial Numbers.....150	
Rear Suspension Race Sag 129	Specifications151	
Suspension Adjustments for Track	Torque Specifications152	
Conditions131	Nuts, Bolts, Fasteners152	
Suspension Adjustment Guidelines 132	Oxygenated Fuels155	
Tuning Tips 135	Competition Logbook156	
Spark Plug Reading..... 135	Optional Parts List158	
Steering Damper Adjustment 136	Spare Parts & Equipment159	
Steering Damper Damping..... 136	Spare Parts159	
Steering Damper Adjustment Guidelines 137	General Tools.....159	
Chassis Adjustments 138	Honda Special Tools159	
Rear End..... 138	Chemical Products159	
Fork Height/Angle..... 138	Other Products159	
Wheelbase 138	Wiring Diagram160	
Gearing 139	CONSUMER INFORMATION.....161	
Tire Selection for Track Conditions 140	Authorized Manuals162	
Personal Fit Adjustments 141	Contacting Honda163	
Control Positioning 141	Your Honda Dealer164	
Handlebar Position, Width & Shape 141	The Honda Rider's Club (USA only)165	