

Index

A

- accessories 3
- adjustments,
 - chassis..... 138
 - control freeplay 58, 61, 90
 - for competition 111
 - gearing..... 139
 - personal fit..... 141
 - steering damper 136
 - suspension, front..... 112
 - suspension, rear 127
 - suspension, track conditions..... 131
 - tire selection, track condition 140
- after competition maintenance 31
- air cleaner 55
- air pressure,
 - front suspension..... 112
 - tires..... 95
- apparel, protective 2
- appearance care 109
- authorized manuals..... 162

B

- basic operation..... 15
- before riding 11
- between motos & practice maintenance..... 30
- brakes,
 - fluid level..... 91
 - lever, front adjustment..... 90
 - pad wear 93
 - pedal height 90
- break-in guidelines 19

C

- capacity, fuel39
- care, appearance109
- chain drive.....97
- chassis adjustments 138
- cleaner, air.....55
- cleaning, appearance care.....109
- clutch system, adjustment61
- competition logbook156
- consumer information161
- contacting Honda163
- controls.....5
- coolant.....53
- customer service.....164
- cylinder system78

D

- damping adjustments,
 - front.....112
 - rear128
 - steering damper.....136
- dealer, your Honda.....164
- diagram, wiring160
- drive chain.....97

E

- engine,
 - flooded.....17
 - idle speed60
 - lacks power.....147
 - number.....150
 - oil.....48
 - pinging.....39
 - starting17
 - stop button18
 - stopping18
 - won't start.....147
- environment, protecting.....146

F

- filter,
 - air.....55
 - fuel pump.....43
 - oil.....49
- flooded engine, starting17
- fork,
 - front suspension adjustment112
 - front suspension inspection86
 - oil recommendation88
- front brake lever adjustment90
- front suspension maintenance.....112
- fuel39
- fuel,
 - line inspection.....39
 - line replacement.....40
 - oxygenated.....155
 - pump filter43
 - refueling.....39
 - system39
 - tank capacity.....39