

Index

A

- accessories 3
- adjustments,
 - chassis..... 148
 - control freeplay 59, 62
 - for competition 119
 - gearing 149
 - personal fit 151
 - steering damper 146
 - suspension, front..... 121
 - tire selection, track condition 150
- after competition maintenance 32
- air cleaner 56
- air pressure,
 - balance chamber 124
 - front suspension..... 121
 - inner chamber 123
 - tires 103
- apparel, protective 2
- appearance care 117
- authorized manuals 172

B

- balance chamber air pressure..... 124
- basic operation 15
- before riding 11
- between motos & practice maintenance 30
- brakes,
 - fluid level..... 99
 - lever, front adjustment..... 98
 - pad wear 101
 - pedal height 98
- break-in guidelines 19

C

- capacity, fuel40
- care, appearance 117
- chain drive 105
- chassis adjustments 148
- cleaner, air56
- cleaning, appearance care..... 117
- clutch system, adjustment62
- competition logbook 166
- consumer information 171
- contacting Honda 173
- controls 5
- coolant 54
- customer service 171
- cylinder system 79

D

- damping adjustments,
 - front 121, 122
 - rear 138
 - steering damper 146
- dealer, your Honda 174
- diagram, wiring 170
- drive chain 105

E

- engine,
 - flooded 17
 - idle speed 61
 - lacks power 157
 - mode select button 120
 - number 160
 - oil 49
 - starting 17
 - stop button 18
 - stopping 18
 - won't start 157
- environment, protecting 17, 156

F

- filter,
 - air 56
 - fuel pump 44
 - oil 50
- flooded engine, starting 17
- fork,
 - front suspension inspection 87
 - oil recommendation 89
- front brake lever adjustment 98
- front suspension maintenance 121
- fuel 40
- fuel,
 - line inspection 40
 - line replacement..... 41
 - oxygenated 165
 - pump filter 44
 - refueling 40
 - system 40
 - tank capacity 40