

G

gap, spark plug 67
 gasohol 165
 gasoline 40
 gearing 149
 guidelines,
 steering damper 147
 suspension adjustment 142

H

handlebar inspection 115
 Honda,
 contacting 173
 Rider's Club 175
 service manual 172
 your dealer 174

I

identification, vehicle 160
 idle knob, fast 17, 61
 idle speed, engine 61
 indicator,
 circuit inspection 8
 DTC index 9
 MIL blink 7
 mode 10, 120
 inner chamber air pressure 123
 inspection, pre-ride 13
 instruments 5

L

labels, safety 4
 logbook, competition 165

M

maintenance,
 after competition 32
 before & after competition 30
 between motos & practice 30
 component locations 33
 general competition 26
 importance 22
 safety 23
 schedule 24
 manual, service 172
 mode indicator 10, 120
 modifications 3

O

oil,
 engine 49
 fork 89
 transmission 52
 operating instructions 15
 operation component locations 6
 optional,
 parts list 168
 sprockets 149
 oxygenated fuels 165

P

pads, brake 101
 parts, optional 168
 personal fit adjustments 151
 ping, engine 40
 plug, spark 67
 pre-load, rear suspension 137
 pre-ride inspection 13
 protective apparel 2

R

rear suspension adjustment 144
 Rider's Club Honda (USA only) 175
 riding,
 apparel 2
 basic operation 16
 before 11
 important safety information 2
 safety precautions 2

S

safety,
 a few words about Safety Messages
 important information 2
 important precautions 2
 labels 4
 maintenance 23
 riding precautions 16
 schedule, maintenance 24
 seat 34
 serial numbers 160
 service,
 customer 171
 manuals 172
 spare parts 169
 spark knock 40
 spark plug,
 maintenance 67
 reading 145
 specifications 161
 spring pre-load, rear suspension 137
 starting,
 engine 17
 troubleshooting 157
 steering damper,
 adjustment 146
 guidelines 147
 operation inspection 112

(cont'd)