


Instruments *(Continued)*

- 3 Return to the previous screen or the Home screen.  P.24

Setting range: Level 1 to 8 or [AUTO]
Default: [AUTO]

The display can become dark when the display is very hot. If it does not restore the original brightness, contact your dealer.

Automatic Brightness Control:  P.210


Day / Night





You can select the timing for changing the map color to improve the visibility of the map.


The system automatically changes the map color according to the selected level.


When [Hold day mode] is selected, the map is always displayed with daytime color.

When [Hold night mode] is selected, the map is always displayed with nighttime color.



- 1 Select [Day / Night], and then press  or [ENT] switch.
- 2 Rotate  or press  /  on the 4-way key switch to select [Hold day mode], [Hold night mode] or your preferred level.



- 3 Return to the previous screen or the Home screen.  P.24

Setting range: Level 1 to 8, [Hold day mode] or [Hold night mode]
Default: Level 4