

(ABS) Combined ABS indicator

Comes on when the ignition switch is turned ON. Goes off when your speed reaches approximately 3 mph (5 km/h).

If the indicator comes on while riding:


➔ P.175

High coolant temperature indicator

Comes on briefly when the ignition switch is turned ON.

If the indicator comes on while riding:

➔ P.174



(P) Parking brake indicator

GL1800BD/D/DA

Comes on as a reminder that you have not released the parking brake lever. ➔ P.60