

D	
D (AT MODE) Indicator	39
D Switch	52, 113
Digital Clock Adjustment	77
E	
Elapsed Time	26
Electrical Adjustable Suspension	29, 168
Electrical Trouble	203
Emergency Key	208
Emission Control Systems	223
Engine	
Number	221
Oil	145, 154
Oil Filter	155
Overheats	174
Starting	110, 111
Stop Switch	52, 110, 111, 210
Will Not Start	173
Environment	220
Equipment	
Fairing Pocket	127
Helmet Holder	129
Helmet Holder Hanger	129
Saddlebags	126
Shelter Case	129
Tool Kit	130
Travel Trunk	126

F	
Fairing Pocket	127
Final Drive Oil	146, 159
Flooded Engine	111
FM Radio	90
4-way Key/ENT Switch	50, 51
Front Brake Lever Adjustment	167
Front Suspension	168
Fuel	
Average Fuel Mileage	26
Current Fuel Mileage	26
Gauge	38, 179
Low Fuel Indicator	44
Recommended	125
Remaining	38
Tank Capacity	125
Fuses	145, 205
G	
Gasohol	227
Gasoline	125
Gear Position Indicator	39
Gear Shift Operation	114
H	
Handle Grip Heater	131
Handle Grip Heater Button	48
Handle Grip Heater Indicator	42, 179
Hazard Switch	52
Headlight Aim	167
Headlight Dimmer Switch	50, 51

Helmet Holder	129
High Beam Indicator	45
High Coolant Temperature Indicator	47, 174
Hill Start Assist	124
Hill Start Assist (HSA) Indicator	46, 124, 178
Home Button	48
Home Switch	50, 51
Honda Contacts	230
Honda Selectable Torque Control (Torque Control)	120
Honda SMART Key	208
Answer Back Button	54
Battery	170
LED	54
ON/OFF button	54
UNLOCK Button	54
Honda SMART Key Battery	170
Honda SMART Key Does Not Operate Properly	184
Honda SMART Key Indicator	45, 176
Honda SMART Key System	56, 212
Horn Button	50, 51
HSTC (Honda Selectable Torque Control)	31