

# Auxiliary Function

## Auxiliary (AUX) Input

Use this function to listen to other audio:


Connect the input jack connector to listen to other audios.

Connect the iPod®/USB flash drive to the USB cable to operate and listen to it (see [page 130](#)).

- To turn the function on — push the AUX button once. (AUX appears on the display.)  
push the AUX button twice when connecting a USB device with USB cable (see [page 134](#)). (iPod® or USB appears on the display.)
- To turn the function off — push the AM, FM, XM® or WB button.


The following functions operate the same as they do with the AM/FM radio: Switch output, Tone control, Fader control, SRS, AVC, BEEP, Muting.

(Models not equipped with Navigation System)



AUX button

(Models equipped with Navigation System)



AUX button

The display changes as follows each time the AUX button is pushed.

