
## Windscreen Ventilation Louver



You can adjust the windscreen ventilation louver with the lever to control and direct the flow of fresh air.