


## Windscreen Ventilation Louver

You can utilize the windscreen ventilation louver to direct the flow of fresh air.

### To Operate the Windscreen Ventilation Louver

Press the release button, then the windscreen ventilation louver pops-up.



### To Close the Windscreen Ventilation Louver

Push the center of the louver until the louver is firmly closed.