


Checking the clutch and front brake

Checking the free play of the clutch lever and the front brake lever

Check the free play of the clutch lever and the front brake lever.

Free play of the clutch lever and the front brake lever: 5 to 15 mm



Check the clutch cable and the front brake cable for kinks or signs of wear. If necessary, have your dealer replace it.