

Tool Kit

The tool kit is stored in the tool kit compartment under the driver's seat.

To access the tool kit, open the left door (page 31), left side net (page 33) and remove the left seat (page 91), and then remove the rubber dust cover.

An optional, larger tool kit may be available. Check with your Honda dealer's parts department.

UNDER LEFT SEAT

